


Ring End Insert Tools

- With pin lock
- *) = please consider the depth gauge (s) for correct calculation of the torque value




Art. Code	mm	mm	s mm	b mm	h mm	g	
6191 0070	9 x 12	7	17,5	13,0	8	38	1
6191 0080	9 x 12	8	17,5	14,2	8	37	1
6191 0100	9 x 12	10	17,5	17,2	9	40	1
6191 0110	9 x 12	11	17,5	18,5	9	42	1
6191 0120	9 x 12	12	17,5	20,0	12	51	1
6191 0130	9 x 12	13	17,5	21,5	12	51	1
6191 0140	9 x 12	14	17,5	23,0	12	53	1
6191 0160	9 x 12	16	17,5	25,7	13	56	1
6191 0170	9 x 12	17	17,5	27,2	13	55	1
6191 0180	9 x 12	18	17,5	28,5	13	60	1
6191 0190	9 x 12	19	17,5	30,3	13	64	1
6191 0210	9 x 12	21	17,5	33,0	15	68	1
6191 0220	9 x 12	22	17,5	34,5	15	71	1
6191 1130	14 x 18	13	25,0	21,5	11	130	1
6191 1140	14 x 18	14	25,0	23,0	11	132	1
6191 1160	14 x 18	16	25,0	25,7	12	137	1
6191 1170	14 x 18	17	25,0	27,2	12	141	1
6191 1180	14 x 18	18	25,0	28,5	12	139	1
6191 1190	14 x 18	19	25,0	30,5	12	145	1
6191 1210	14 x 18	21	25,0	33,0	15	152	1
6191 1220	14 x 18	22	25,0	34,5	15	157	1
6191 1240	14 x 18	24	25,0	37,5	15	162	1
6191 1270	14 x 18	27	31,0*	41,5	17	205	1
6191 1300	14 x 18	30	31,0*	45,0	19	205	1
6191 1320	14 x 18	32	31,0*	47,5	19	214	1
6191 1340	14 x 18	34	31,0*	50,5	19	226	1
6191 1360	14 x 18	36	31,0*	53,0	19	230	1
6191 1380	14 x 18	38	31,0*	53,0	19	230	1
6191 1410	14 x 18	41	31,0*	59,0	20	235	1



Flared Ring End Insert Tools

- With pin lock
- *) = please consider the depth gauge (s) for correct calculation of the torque value



Art. Code	mm	mm	s mm	b mm	h mm	g	
6192 0100	9 x 12	10	17,5	21,0	11,0	40	1
6192 0110	9 x 12	11	17,5	22,5	11,0	40	1
6192 0120	9 x 12	12	17,5	23,7	11,0	40	1
6192 0130	9 x 12	13	17,5	25,2	11,0	40	1
6192 0140	9 x 12	14	17,5	27,0	12,0	50	1
6192 0170	9 x 12	17	17,5	31,5	12,0	65	1
6192 0180	9 x 12	18	17,5	33,0	14,5	65	1
6192 0190	9 x 12	19	17,5	34,5	14,5	65	1
6192 0220	9 x 12	22	20,0*	39,0	14,5	65	1